
FlexiSpot

Item No. XC6-BG-UK/XC6-OB-UK

User Manual


Warranty




+44 20 3929 3835
info@flexispot.co.uk

Component list


(1)X1



(2)X1



(3)X1




(4)X1



(5)X1



(6)X4




(7)X1




Assembly Instructions


1




2



3



4



Important Safety Instructions

1. It is important to ensure that the furniture is perfectly level before use.
2. Do not use this product if it is damaged.
3. Do not place heavy objects on the non-load-bearing parts of the furniture.
4. Be careful when moving the product. Before lifting the product, secure the mechanism to prevent accidental opening or movement. Never move the product by the mechanism, leg rest, handle, backrest, or swivel base.
5. Connections, if loose, should be locked in time. Use in an unlocked condition is prohibited.
6. To avoid injury or trapping, do not put your hands into the iron frame and internal structure when unfolding the armchair.
7. Sit down slowly in the unit. Do not put your body weight on the back of the product to prevent tipping. Slowly move the product into or out of the tilted position, making sure there are no children or pets nearby.
8. Do not sit alone on the armrests or in front of the unfolded seat.
9. Keep children and people with disabilities under close supervision during use of this product.
10. Keep upholstery away from flames or lit cigarettes. Upholstery can burn quickly and produce toxic fumes and smoke.
11. Please plan and provide a clear operational path for the back and legrest. Position tables and area rugs at a distance that prevents any rubbing or interference, allowing the legrest to extend fully. When fully reclining the sofa, ensure at least 50cm space between the sofa and the wall.

Maintenance and Care Methods

1. Cleaning and regular maintenance will prolong the life of your upholstered furniture. Depending on the intensity of use, it is advisable to brush the upholstery regularly with a soft brush made of natural bristles or to vacuum it with the upholstery nozzle of a vacuum cleaner.
2. If the liquid is spilled on upholstered furniture, the excess must be wiped up immediately with an absorbent cloth. Do not scrub vigorously as this will only cause the stain to penetrate deeper into the fabric. Then remove the stain with warm water, neutral soap, and a clean, soft sponge.
3. The use of chemical cleaners such as acetone, alcohol, acid, or benzene may affect the color of the fabric.
4. DRY THOROUGHLY: Give the suite plenty of time to dry completely after washing with water and natural soap. Normal room temperature is the ideal drying time. BE CAREFUL WHEN DRYING WITH HOT AIR (hair dryer, hot air blower): Synthetic materials are heat sensitive.
5. Light-colored fabrics can become discolored as the dye rubs off non-colourfast fabrics such as dark denim. If the dye from the jeans continues to rub off on the upholstery fabric even after several washes, this is clearly a problem with the clothing fabric and not with the quality of the upholstery fabric.
6. Also be cautious with sharp objects such as jewelry, belts, pet claws, and shoe buckles. These objects have the potential to scratch or damage the cover.

Manufacturer: Loctek Ergonomic Technology Corp.
Add.:588 Qihang South Road Binhai Industrial Zone, Yinzhou District Ningbo, Zhejiang 315145 P.R. China

Importer: FLEXISPOT LIMITED, G-PARK UNIT1, MOULTON PARK, SUMMERHOUSE RD, NN3 6WD NORTHAMPTON, UK