


FlexiSpot

Item No.C7-Air-Pro
User Manual



Warranty



+44 20 3929 3835
info@flexispot.co.uk




PARTS

A	B	Cx5	D	Kx3+1 (M8X20MM)
E	F	G	H	Lx6+1 (M6X25MM)
				Mx4+1 (M6X30MM)
				Qx1
				P x1+1 (M6X30MM)

Assembly Instructions


Before assembling this product, please read these instructions carefully.

1




3

Pull the footrest outwards




2




4

Step a: Push the handle upwards.
Step b: Press the mechanism and then push it to the end following the arrow direction, so the screw holes appear.




5




Note: Do not unscrew the pre-installed screws and washers. The positions of the base screw holes are indicated by the arrows in the picture.


6




7



8




9




Attention: If you find the lumbar support too firm, you can choose to put the cover on it. Please be careful not to hurt your hands when doing this.


10




Headrest 45° adjustment




Headrest up and down adjustment




Armrest height adjustment




Armrest forward and backward adjustment




Armrest 360° rotation adjustment




Seat cushion forward and backward adjustment




Pushing the handle downward allows the seat cushion to slide forward by 60mm. Releasing the handle can lock it within the range of movement.




This handle controls the reclining angle of the chair backrest




Handle up adjusts seat height



Pull the footrest forward, then hold the button to rotate the footrest clockwise



Press and hold the button to rotate the footrest counterclockwise. Then, push the footrest backward to retract it



The lumbar support can be adjusted up and down.
Note: The switch is used for vertical positioning rather than full locking. Positioning is achieved through slots that provide light fixation and resistance at the optimal position.

Recommended to use B position to get dynamic support

A is locked position
B is unlocked position

Safety Instructions

WARNING: Failing to follow the instructions below may result in serious injury!

1. This product is for sitting only, it is strictly forbidden to stand on the product or to use it as a ladder, etc;
2. Use this product only when all screws and parts are locked. Check the locking of all screws and parts at least every 3 months;
3. If any parts are missing, damaged, or worn, stop using the product and repair it with factory-supplied parts;
4. It is strictly forbidden to sit on the armrests of the product;
5. This product is designed as a one-person seat and is limited to one person per use;
6. Children under the age of 10 should use this product under adult supervision.

Manufacturer: Loctek Ergonomic Technology Corp.
Add.: 588 Qihang South Road Binhai Industrial Zone, Yinzhou District Ningbo, Zhejiang 315145 P.R. China
Importer: FLEXISPOT LIMITED, G-PARK UNIT1, MOULTON PARK, SUMMERHOUSE RD, NN3 6WD NORTHAMPTON, UK