


FlexiSpot

Item No. XL6-Air

User Manual



+1 (855) 585-5618



ASSEMBLY GUIDE

Congratulations, you now have a new lift recliner with massage.


Before you can enjoy its comfort, some assembly is required. This guide will walk you through the essential steps to put it together. To ensure everything goes seamlessly, please adhere to the assembly instructions and **pay special attention to the important safety guidelines.**

While it's feasible to assemble the recliner by yourself, **having a second person to help can make the process even easier.**


Before starting, please verify that all parts are present in the package. If you encounter any issues or missing pieces, feel free to send us an email, and we'll assist you promptly.




Component List




Seat




Backrest




Back frame




Handrail




Handrail




Sofa remote control




Motor power supply




Power line



Stabilizer



M6 claw nut




screw M6 * 40mm

ASSEMBLY INSTRUCTION


1 Install Stabilizers

Turn the screw (L) through the seat frame (A) and the stabilizer (J) in succession, then secure it with the nut (K) and the screw (L). Tighten them completely.




2 Install the Right Armrest

Insert the arms (D) into the seat (A) in a way that they fit properly. You will hear a click when they are securely engaged.




3 Install the Left Armrest

Repeat Step 2. Insert the arms (E) into the seat (A) in a way that they fit properly.



4 Assemble the Backrest


Place the Back frame (C) on the back of the backrest (B), connect their top sides with a zip tie, and then use the velcro on the bottom of the backrest to bind their bottom sides together.



5

Install Backrest


1. Position the backrest in alignment with the cushion and insert the buckle. Applying gentle pressure on the upper part of the backrest until a satisfying click sound is heard, indicating that the installation is now complete.
2. Connect the white and red cable on the backrest to the corresponding cables on the base, making sure the colors match (white with white & red with red).



6


Connect Cables

1. Connect the cable on the armrest side to the suitable plug
2. Locate the remote control (F) and connect to the corresponding receiver on the seat base. The protective cover should be fixed after the cable is connected.
3. Find the power adapter (G) and connect it to the corresponding receiver; Connect one end of the adapter power cord (H) to the power adapter (G).
4. Plug the power cord of the adapter into a power outlet. The indicator light on the adapter will illuminate once all connections have been established.





7

Congratulations! You've assembled your sofa!



Note: Since the cushion is packed in compression, after the product is installed, you need to tap and adjust the cushion which can help restore fullness. After two days, you will get an Overstuffed Recliner as picture shows.


OPERATING INSTRUCTION



Cup holder pulled out


Diagram of Remote Usage

Read all instructions before using the item



How to Disassemble

Please find a strong tool to prod the small piece of metal grooves, then the backrest will be pulled out. The tool is not included.



Specifications of power adapter

The power is on in the standby state. The user can activate the function via the

hand controller.

Input:AC100-240V,50HZ/60HZ;Output:DC12V2A

Product features

- 1、 8 points massage
- 2、 One-way switch for independent heating plate operation
- 3、 Three-segment timing, with a default shutdown time of 10 minutes.
- 4、 Three levels of vibration intensity
- 5、 3 vibration modes

Function details

- 1、 Switch on and off
- 2、 TIME: Cycling through massage durations (10/20/30 min). Default startup is 10minutes.
- 3、 MODE: Tap the three vibration modes to switch(M1/M2/M3). The default startup mode is M1.
- 4、 INT: Switch intensity by vibration strength (H/M/L). Default startup is M (medium).
- 5、 HEAT: Click to toggle heating.
- 6、 Massage Intensity Levels
- 7、 Massage duration

Maintenance and Care Methods

- To maintain the recliner's quality, it is recommended to position it at a minimum distance of 30cm from direct exposure to sunlight. Every 10-15 days, it is advisable to utilize a vacuum cleaner to eliminate dust and other particles, ensuring a thorough cleanliness of the recliner.
- To ensure the everlasting smooth quality of the fabric, it is crucial to promptly address any stains before resorting to scraping or employing other destructive treatments. A protective cover can be placed over the recliner surface as a preventive measure. In case of ink stains, using a gentle white cloth or absorbent paper to carefully wipe them away will effectively remove any residue.
- If you need to use solvent to remove stains, please avoid applying it directly onto the stained area. Instead, pour the solvent onto a clean cloth and then use the cloth to gently blot the stains. To ensure safety, it is recommended to perform a cleaning test on a hidden area at the back before treating the stains. When treating the stains, start wiping them in a circular motion from the outside towards the center, until the stains are completely removed. Finally, immediately after wiping, use a low-power hair dryer to gradually dry the area, starting from the outer edges and moving towards the center.
- When wiping stains, it is important to be gentle and exercise caution, avoiding applying excessive force. To protect your recliner, you can consider using a removable and close-fitting protective cover.
- If you have adorned your sofa with a close-fitting protective cover, clean it by following the guidelines mentioned on the cover using an oxidizer lotion free from bleach. Neglecting to do so may result in an alteration of the texture and hue of the recliner's fabric.
- Regular Vacuuming

Make it a habit to vacuum your recliner at least once a week, giving special attention to the corners where dust tends to accumulate. In case you notice any stains, gently wipe them with a clean cloth dampened in water to prevent leaving behind any marks. For best results, begin wiping from the outer edges of the stain towards the center.

• Effective Cleaning Methods

To clean effectively, start by using warm distilled water to eliminate fat and acid contamination. Moisten a clean cleaning cloth and scrub from seam to seam. For stains that contain protein, such as blood or urine, it is recommended to use ice water. Dry stains usually require scrubbing with a pH neutral soap or thymol. Dilute the foam and apply it to the stain, and if you are dealing with a large area, wash from the outside towards the inside. Afterward, use a clean cloth and diluted distilled water to wipe the surface. To get rid of any remaining moisture, use a dry cloth. In case you come across difficult stains like blood, gum, or ballpoint pen marks, it is advisable to seek professional help or ask for advice on the best method to remove them.

• How to remove stubborn stains

If there is gum or other glue on the recliner, you can use an ice pack or ice water to cool down and then gently wipe off with a fine cloth.

Product Precautions

1. Unpacking and Checking

- Prior to opening the package, it is advisable to examine the package for any signs of damage or tampering. Once unpacked, carefully inspect the product's external condition for any dents, scratches, or other potential issues. Subsequently, ensure that all accompanying accessories are present and accounted for. Avoid utilizing sharp tools during the unpacking process to prevent any unintended harm or damage to the recliner's surface;
- After the product undergoes prolonged transportation over long distances, it is expected that temporary indentations may form. However, it is natural for these indentations to gradually recover after the product is used for a certain period of time.

2. Transportation and Storage

- Before relocating furniture, it is crucial to ensure that items are removed to avoid any potential harm caused by falling components during the furniture moving process. This precautionary measure is vital to ensure the safety of individuals involved.;
- When it comes to relocating furniture, it is essential to lift it carefully and place it in an appropriate position before gently lowering it. During the moving process, it is advisable to refrain from pulling or exerting excessive force to prevent any potential damage, such as loosening or breaking the iron frame and internal structure;
- When you relocate your furniture, it is crucial to ensure that its base is securely grounded in its new position.;
- When disassembled furniture needs to be moved, take it apart and move it.
- When furniture remains idle for an extended duration, it is advisable to shield it using packing materials that are impervious to dust and light. Furthermore, it should be securely positioned within an indoor space that ensures adequate dryness and ventilation.

3. In Use

- Before using furniture, it is important to ensure that it is perfectly levelled.
- It is advisable to refrain from prolonged exposure to sunlight and high-energy lamps, as they can lead to local discoloration or fading.
- Avoid placing any heavy items on the non-load-bearing components of the furniture.
- Connectors, if loose, should be locked in time, prohibit the use of non-locking state.
- Please keep the room ventilated and with normal dryness and humidity to avoid mould and mildew on the body of the recliner.
- When expanding the recliner, please do not put your hands into the iron frame and internal structure to prevent the possibility of hand injuries or pinches;
- Do not sit alone on the armrests or in front of the unfolded seat;3.8. If not used for a long time, the power needs to be cut off;

4. Maintenance

- Try to avoid standing, jumping or sitting hard on your furniture, as this can cause damage to your furniture. Sharp objects (keys, knives) and animal claws can cause damage to your furniture.
- Power off when using wet cloth for maintenance.

Warning

- Sit down in the sofa gently. To avoid tipping over, do not throw yourself into the sofa. Move the sofa into the reclining position slowly, making sure that no children or pets are in close proximity.
- Do not allow children to play on or around the sofa, particularly when it is in an open position.
- Close the recliner completely before getting out of it.
- Never sit on the footrest when it is open, even if it is a child.
- To eliminate the risk of tipping over, do not sit on the arms or foot rest of the sofa.
- This sofa is designed to be used by 1 adult at a time.
- Please forbid people with the following ailments from using this sofa: Those people with severe symptoms of heart disease, high blood pressure, cerebral thrombosis and others who are sensitive to heat or completely insensitive to heat, those with brittle bones or have issues with waist support pregnant women, children and others where it has been determined they are not suitable to use this product under the guidance of doctors.
- To fully recline the sofa, ensure the sofa well, you need to put the sofa at least 19 inches away from the wall or any other obstacle.
- Product can not touch water, fire, etc. Product can also not come in contact with sharp objects (knives, nails, etc.)

Warning




Do not sit on or



Do not press backrest
after recline



Do not get off the chair
after recline



Do not sit/kick/stand on the footrest when
the chair is on reclining position